

**USE YOUR OLD WIRE FOR LENGTH AND  
BENDING LOCATION**

- 1) Using your old wire, locate the bending point for the hook.
- 2) Using your old wire or the templete below, bend to make the “hook” at the proper place, angle, and radius.
- 3) Slide the spring onto the wire and install.

**NOTE:** Some installations require a cone washer between the spring the back baffle.

[www.BaffleWires.com](http://www.BaffleWires.com) | © 2022 Fulgent Air, LLC